TrailMaster 150cc go kart oil change instruction

1. 150cc engine crankcase oil drain plug, transmission case oil drain plug:



2. 150cc Engine transmission case oil lube plug, crankcase oil lube plug:



- 3. For oil change, take of the drain plugs; drain the engine/gear oil completely. The crankcase drain plug has a filter net which must be cleaned separately. Put the drain plugs back.
- 4. Open the oil lube plugs, input the correct oils. 0.25-0.3gal 15W/40 will be used for crankcase lube and 8-9onces 85W/90 will be used for the transmission case lube.