

50 Remote Instructions

1. The picture of 50 Remote:



2. Installation position: at the bottom of Switch Panel Cover (besides Steering Shaft)



3. The purpose of this remote: remote control to shut down the engine. Guardians could use this remote to shut down the engine in the emergency to avoid accidents.

4. Remote introduction:

4.1 Remote start (Att: the key switch must be at “on” position!

Pull the chock button on the dash board.)



4.1.2 Pull up the choke cable button



4.1.3 Press the “⚡” to start the engine; if the go kart was turn off by remote last time, so must press ⚡ twice to start the engine, or press 1time  then press ⚡ to start the engine.



4.2 Remote: turn off the engine

4.2.1 By running go kart press  button and hold until the engine is turned off, max. effective distance of remote operation is 350ft.

Note: 1、 if the go kart was turned off by the remote, for starting must press at first the  or  to unlock, then press  to start.

2、 the key switch must be at “on” position to use the remote for turn on/off